


ACCESSORY BRACKET


SK-AB09, AB10, AB11, AB12, AB14, AB15, AB16, AB17, AB18, AB19, AB20, AB21



ACCESSORY



SK-AB09 : Corner bracket  
For SK-AB06/SK-AB16




SK-AB10 : Corner bracket  
For SK-P440/SK-P441/SK-AB02




SK-AB11 : Wall bracket  
For SK-D106/SK-D107




SK-AB12 : Outdoor pendant bracket  
For SK-H241



SK-AB14 : For SK-V251IR




SK-AB15 : Pole bracket  
For SK-P440/SK-P441/SK-AB02



SK-AB16 : Outdoor wall bracket For SK-H241



SK-AB17 : Steel strap For SK-AB18



SK-AB18 : Pole bracket For SK-AB16



SK-AB19 : Wall bracket For Dome Cameras



SK-AB20 : Wall bracket For SK-V207IR



SK-AB21 : Ceiling bracket For SK-V207IR